

RELN Rain Mate

Concrete Installation

- 1. Carry out ground preparation, base layers, compaction, and pavement design to suit design loads.
- 2. Lay Reln Rain Mate on a bed of compacted sand, cracker dust or road base.
A concrete base for vehicle applications is recommended in poor sub soil.
- 3. Encase RELN Rain Mate in concrete, minimum of 4 inches (100mm). Ensure concrete is consolidated around the channel to eliminate air pockets
- 4. Lay concrete to suit design loads
- 5. Finish top course and concrete 3mm above channel edge

